



(The flasher will alternate regardless of this setting.)

Blink frequency

Alternating frequency

Flash freq is about 4Hz, and alternating freq. is about 1 Hz with the component values shown here.
 Flash freq. can be changed via R2 & C2. Alternating frequency can be changed via C4.
 Maximum 4 LEDs in parallel on each output channel. (Remember resistors!)
 R8 & R9 must be adjustet after supply: 7,2 -> 12V

Simple warning flashers		
Supply: 7,2 - 12 V. Power: 30mA		
Robert H.	Rev 1.0	Page 1/1
	26-02-2011	